


# GTT NB IoT STANDALONE USER GUIDE



Gefle Testtechnik™

**Copyright**

© 2018 Gefle Testteknik AB. All rights reserved.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, storing in an information retrieval system, or translating, in whole or in part, without the prior written consent of Gefle Testteknik AB.

Gefle Testteknik respects the intellectual property of others, and we ask our users to do the same. Gefle Testteknik is protected by copyright and other intellectual property laws.

# 1 Introduction

The GTT NB IoT StandAlone by Gefle Testteknik AB enables demodulation of NB IoT standalone and guardband signals.

## 2 System Requirements

See <http://testteknik.se/content/product> for a list of SW and HW requirements for the product.

Description	Version
HW requirements:	
NI PXIe-1082 chassis (or similar)	
NI PXIe-8135 Controller (or similar)	
SW requirements:	
Windows 7, 10 (32- or 64 bit)	Note 1
NI LabVIEW Full development system	2014
NI Spectral Measurements Toolkit	2.7
NI Modulation Toolkit	4.4
NI-RFSA	14.1
NI-RFSG	14.0.1
NI Third Party Licensing & Activation Toolkit	2014
VI Package Manager	2017
<b>Notes</b>	
Note 1	64-bit recommended. For other Windows versions, please contact <a href="mailto:sales@testteknik.se">sales@testteknik.se</a> for latest status.

## 3 Installation

Start LabVIEW and VIPM with administrator rights and start the installation of the “NB IoT Standalone” using VIPM 2017 or newer.

**Note:** The system supports Windows 10 & Windows 7, 64 bit. For other Windows versions please contact [sales@testteknik.se](mailto:sales@testteknik.se) for latest status.

### 3.1 To activate/deactivate a license

The distributed executables and the GTT LabVIEW libraries (\*.lvlib) are licensed and have an evaluation period of 30 days and must then be activated for continued use. The license is locked to the computer that is used during installation.

We recommend using GTT licensing toolkit for activation of licenses. The built in activation tool in LabVIEW may also be used. Be aware that licenses activated in LabVIEW versions older than 2014 cannot be transferred at a later date, should it be needed.

To transfer a license it must first be deactivated on the system where it is currently active before activation on the new system. When restoring the computer from a backup image deactivation must be performed before deleting the old system.

A product can be manually activated (i.e. offline) by sending an email to [sales@testteknik.se](mailto:sales@testteknik.se) in the following format. NOTE that manually activated licenses cannot be deactivated or transferred:

Company Name:  
User Name:  
Executable User Code 1:  
Executable User Code 2:  
LabVIEW Library User Code 1:  
LabVIEW Library User Code 2:

For further information refer to the preferred tool for activation.

## **4 HW Setup**

Besides HW requirement for the GTT NB IoT Standalone Toolkit this add-on does not require any specific hardware.

## **5 Example**

The example code delivered with the add-on shows how to set up and perform a basic NB IoT Standalone or Guardband measurement. Refer to in code description for details.




Figure 1 NB IoT Standalone and Guardband measurement

## 6 User Interface

Refer to context help for details

## 7 Contact Information

<http://testteknik.se/>

Support contact:

[support@testteknik.se](mailto:support@testteknik.se)

Sales contact:

[sales@testteknik.se](mailto:sales@testteknik.se)